

Owner's Operating Manual & Safety Information

INFLATABLE SPORT BOATS

Dolphin 8.8' Air Floor

Manta Ray 8.8'

Shark 9.8'

Killer Whale 10.8'

On Point Products

2105 Pasqual Dr., Roseville, CA 95661 www.inflatablesportboats.com | (530) 268-4757

Contents

- **3** Operation and Safety
- **4** Watersports Industry Association Responsibility Code
- **5** Product Details
- 6 Assembly and Disassembly
- **9** Inflation
- **10** Operating Information (Loading, Towing, Rowing, Outboard Motor)
- 12 Environmental Protection
- 12 Repairs
- **13** EC Declaration of Conformity
- 14 Warranty Information
- 15 Manufacturer's Certificate of Origin

CIN #: ASTSB#######

(CIN # will be located on the CE Plate on your Sport Boat)

Congratulations! You are now the proud owner of an Inflatable Sport Boat. Inflatable Sport Boats are manufactured to provide a premium inflatable boat with the highest quality material, hand crafted design, durability, and performance to last. These boats are built with a heavy duty UV and puncture resistant PVC material that is welded together to guarantee long lasting exceptional performance for years. Constructed to succeed in providing your multi-sport, all environment, and inflatable tender.

Each boat has an identification number, which you will find on the CE plate under CIN #. The first letter and figures of this ID number have already been printed on the Manufacture Certification of Origin document at the back of this manual. Please complete it by taking down the missing figures/letters. This ID number is to be mentioned in every correspondence with us or any authorized service station. The CIN # is customized for each individual inflatable sport boat made. It is only with this number that we will be able to identify your boat and give you the relevant information.

Operation and Safety Information

WARNING

BEWARE OF OFFSHORE WINDS AND CURRENTS!

It is the responsibility of the boat's operator to know all laws applicable to boats and to comply with those laws when equipping and operating the boat.

Rules and regulations may vary depending on the following conditions: the location of the boat's operation and the requirements of local authorities; the use of the boat, the particular time of the day during which the boat is being used, the conditions under which the boat is being operated, and the size, speed, course, kind of boat (power, oars, etc.) and mode of operation.

In addition to knowing and following the applicable laws, please note the following:

- 1. Each passenger should wear the appropriate clothing and wear an approved life jacket.
- 2. Ensure that all basic equipment is on board the boat, including paddles /oars and an inflation pump. Be aware of the possible necessity of additional safety equipment.
- 3. A boat should not be operated by an individual under the influence of drugs or alcohol.
- 4. Weight must be distributed evenly. If your motor-equipped boat is lightly loaded, do not accelerate suddenly. Stability and handling problems can occur if the operator mishandles the craft.
- 5. The carrying capacity and the engine capacity and maximum weight must not be exceeded.
- 6. Outboard motors are dangerous and can cause injury and death when improperly operated. Never equip or operate your boat with a motor which is not approved for use with the boat. Never approach at speed a swimmer in the water or allow a swimmer to approach the stern of the boat while the engine is running.
- 7. Due attention should be given to winds and tides, which can change and therefore affect fuel consumption.
- 8. When boating in unknown waters, it is always a wise precaution to obtain local knowledge before setting out.
- 9. Always tell someone your time and place of departure, your proposed route and the time you expect to return.
- 10. The display of navigation lights may be required. The user should ensure that the boat should not be operated during darkness or other hazardous weather conditions unless a correct navigational lighting has been fitted and is operating properly.
- 11. Safety courses on boat handling are available in most countries from national or local organizations. Operators should acquaint themselves with the general rules of the waterways and the local water conditions before taking a boat out.
- 12. On extended voyages, due consideration must be given to safety equipment such as flares, first aid kit, anchors, etc.
- 13. Make sure all passengers remain seated at all times during operation.

On Point Products Roseville, CA 95661 | (530) 268-4757

IMPORTANT!!

PLEASE READ THIS INSTRUCTION MANUAL THOROUGHLY BEFORE ASSEMBLING OR USING PRODUCT. FAILURE TO ABIDE BY INSTRUCTIONS AND WARNINGS CAN CAUSE A MISUSE OF THE PRODUCT AND POTENTIAL INJURY HAZARD

WATERSPORTS INDUSTRY ASSOCIATION RESPONSIBILITY CODE

Be aware that there are risks in boating and Watersports that good judgment and personal awareness can help reduce. To increase your enjoyment of boating and watersports, review these elements of the Code.

IN WATERSPORTS IT IS YOUR RESPONSIBILITY TO:

- ALWAYS familiarize yourself with applicable laws, waterways, and inherent risks
- ALWAYS wear a properly fitted life jacket approved by your country's agency
- ALWAYS read user's manual and inspect equipment before use
- ALWAYS ride under control, at proper speeds, and within your limits
- ALWAYS turn ignition off when anyone is near watercraft power drive unit
- ALWAYS stay clear of engine exhaust to avoid Carbon Monoxide poisoning
- NEVER ski or ride near swimmers, shallow water, other boats, or obstacles
- BE AWARE and keep clear of swimmers and divers. Be aware of beaches and launch sites where people are most likely in the water. Shut off motor whenever in doubt of operating near someone or something in the water.
- NEVER operate watercraft, ski, or ride under the influence of alcohol or drugs
- THE CAPTAIN of the boat is responsible to make sure all passengers have read the warnings and abide by rules.
- ALWAYS stay seated and never stand in the boat while moving.
- MAKE SURE the boat is completely inflated before operating.
- NO BOW RIDING. Bow riding is illegal in most areas and is extremely dangerous.
- KEEP ARMS AND LEGS INSIDE the boat at all time during use.

Safety, Rules, and Regulations

Rules and regulations can change depending on many different circumstances. The place or time of boat operation, the different requirements of local authorities on water rules, boat lights, speed restrictions, and many other boating rules that should be understood before operating the boat.

- In most countries, safety and boating education is available (sometimes mandatory). Captains are responsible to know the general rules and requirements prior to operation.
- Sport Boats **DO NOT** come equipped with a light for driving in the dark.
- Always check the weather before operation. DO NOT use boat during winds or offshore currents.

Product Details

Inflatable Sport Boats offer a multitude of different sizes and types of inflatable dinghy boats. Please make sure to identify which Sport Boats model you have before reading these instructions.

MODELS	LENGTH	WIDTH	CHAMBERS	MAX HP	MAX LOAD	MAX PERSONS
DOLPHIN AIR FLOOR	8'8"	5′	3 + 1	10 HP	1,070 lbs	4
MANTA RAY	′ 8′8″	5′	3 + 1	10 HP	1,070 lbs	4
SHARK	9'8"	5′	3 + 1	15 HP	1,158 lbs	5
KILLER WHALE	10'8"	5′	3 + 1	15 HP	1,268 lbs	5


Assembly and Disassembly

Inflatable Sport Boats are manufactured to make it easy for consumers to set up and take down quick and easy.

ATTENTION! Never use a compressed air source, such as an air compressor. Compressed air can cause over-inflation and potentially damage the product by rupturing seams and bulkhead.

Step by step Assembly

- 1. Remove the boat from the box and lay it out on a clean flat surface with no sharp objects. Make sure the boat is completely spread out with nothing on it or below it before assembly.
- Remove the valve cover and use a boat inflator to inflate the PVC tubes to about 50% capacity. We personally recommend using a vacuum with blow function or a Metro Vac Inflator found at www.inflatablesportboats.com..




* DO NOT INFLATE THE KEEL UNTIL FLOOR BOARDS HAVE BEEN INSTALLED *

Boats with Inflatable Air Floor

- 1. Unfold and stretch out the floor onto the bottom of the boat, edging it under the half-inflated tubes and against the transom. The valve must face upwards.
- **2.** Inflate the floor up to 75%.
- **3.** Finish inflating the boat.
- **4.** Finish inflating the floor.

Boats with Aluminum Floor


- 1. Identifying numbers on floor boards must face upwards.
- 2. Insert floor board #1 in bow of boat.
- **3.** Insert floor board #4 in transom of boat.
- 4. Insert floor board #2 into floor board #1.
- Insert floor board #3 into floor boards #2 and #4 and press down until flat.



Side Joiner Assembly

1. Once the tube is 50% inflated, use an oar (a) to prop up the bottom to raise the floor boards (b) about 1-2 inches off the flat surface. Attach side joiners (c). Repeat the

procedure on opposite side of the boat. If you have more than one joiner on each side, start with one long, one short joiner on one side and with one short and one long on the other side. (asymmetric)



2. Finish inflating the tube one after the other in order to maintain equal amount of air. Do not fully inflate any chamber at one time. Make sure the tube is 100% inflated and firm. An under

inflated tube will cause the boat to not work properly and could potentially damage the product and cause injury risk.

3. Inflate the keel and close valve caps. Close valve properly by making sure the spring inside is popped completely out. No air should be coming out of the valve before placing the cap back on.

Your Inflatable Sport Boat is ready to go!

Step by step Disassembly and Storage

- **1.** Follow step #1 in assembly.
- 2. Wipe down product completely before deflating. It is easier to clean while inflated. **IMPORTANT:** storing a wet product can cause mildew, mold, and can damage the product.
- **3.** Lift and remove one of the middle floorboards first. Remove bow and transom boards last. Place floorboards, side joiners, and oars in carry bag.
- 4. Use an inflator on "sucking function" to remove excess air from each chamber.
- **5.** Fold each side of the boat into the middle. Go to the bow and roll up like a sleeping bag and place in bag.

Cleaning your Boat

Sport Boats are manufactured with a heavy duty 1100 denier weather resistant UV protected PVC material. The PVC material doesn't require any special type of cleaning agent. We recommend rinsing your boat out with general dish soap before disassembly. Let the boat dry 100% before placing in a **dry storage place**.

IMPORTANT:

- Storing a wet product can cause mildew, mold, and can damage the product. Store in a dry, covered, cool area. Storing in damp or humid areas can cause glued areas to separate. Avoid areas that have mice or rodents.
- DO NOT USE PRODUCTS CONTAINING PETROLEUM DISTILLATES. (i.e. Armoral).

Inflation

Inflation takes approximately 8-12 minutes to completely fill the boat. Each size boat has a "Maximum PSI" clearly stated on the CE plate mounted on the boat. *Never exceeded the maximum PSI..*

To Inflate:

- **1.** Use the foot pump provided in the product box. You can not over inflate the product by using the foot pump.
- 2. You can also use any electric boat tube inflator. If the electric inflator doesn't have a PSI meter, inflate the boat 80% and then use the foot pump to achieve proper PSI pressure.
- Maximum PSI can change for each boat. Boat pressure can fluctuate with climate change and must be monitored by boat owner before every use.
 a. It is a good rule to check air pressure before every use.
- **4.** Higher altitudes could change the air pressure. If the boat is inflated when at sea level and is moved to a higher altitude, while being inflated, the air pressure must be reduced to prevent over inflation.
- 5. PSI guide:
 - a. Boat tube Maximum 3.6 PSI
 - b. Keel Maximum 4.5 PSI
 - c. Inflatable "Air Floor" Maximum 8 PSI
- **6.** If you plan on leaving your Sport Boat inflated for a 2-3 day period, it may lose pressure and require re-inflation before use. This is common due to climate change..

Operating Information

CAPTAIN'S READ!

It is the responsibility of the captain/driver of the boat to know all the laws applicable to boats and to follow those laws when operating the watercraft. The captain of the boat is fully responsible for all passengers and making sure the passengers have read and understood all rules and warnings that apply while occupying the watercraft.

Loading

Do not exceed maximum capacity stated on each boat CE plate.

- Each person in the boat should wear a life jacket (PFD personal flotation device)
- Oars or paddles and repair kit should be carried on board for emergencies.
- All loads should be distributed evenly for proper boat trim.

Rowing

- 1. Inflatable boats are equipped with oars and thole-pins.
- 2. Install oars in thole-pins; attach thole-pin cap screws. *Note: Do not use oars as levers, they could break!*
- **3.** Local water conditions must be taken into account before operating the boat with oars or a small outboard motor. Boat power may not be strong enough to overcome currents in tidal inlets, small channels or shallows of shoalwater regions.

Operating Outboard Motor

WARNING! Do not over power and exceed the maximum weight of the motor! Overpowering can result in severe handling and/or stability problems with serious consequences.


Use a safety lanyard

- 1. Regular checks should be made on motor attachment screws. Loose screws will cause erratic boat operation and possibly the loss of your outboard motor.
- 2. Read the manual carefully before assembling or operating the boat.
- **3.** On board, check that the loads are not chafing and puncturing the boat's PVC tube.

Towing your Sport Boat

The inflatable should only be towed using the D-rings near the bow on each side of the boat. Attach both D-rings to create equal tension on both sides before starting to

tow. Make sure the Sport Boat is completely empty before towing process begins. *These boats are not built to tow other watercrafts, water tubes, people, floating devices, etc.*



Anchoring & Mooring

The 3 bow D-rings are for anchoring and mooring.

Air Chamber Failure

If an air chamber gets punctured during use, shift all the interior weight to the opposite side. Use your hand or any available material to prevent further air leakage and get to the nearest shore immediately.

Carbon Monoxide

The exhaust from the engine on a watercraft contains Carbon Monoxide (CO) which is a colorless, odorless and poisonous gas. Excessive exposure to CO can cause severe injury or death. Follow this advice to avoid injury.

- Never "Platform Drag" by holding onto the boarding platform or be dragged directly behind the watercraft. This is where CO will be present.
- Do not sit on the watercraft transom or boarding platform while the engine is running.
- Make sure the engine is properly tuned and running well. An improperly tuned engine produces excessive exhaust and CO.
- If you smell engine exhaust, do not stay in that position.
- Go to the United States Coast Guard's website: www.uscgboating.org for more information on how to help protect yourself and others from the dangers of CO.

Environment Protection

Keep the oil and gas containers inside the boat, anchored/weighed or strapped down at all times while boat is in use. In case of oil or fuel leakage, reduce leak as much as possible, recuperate the waste, and head to the closest shore. Contact the local environment state board about leakage situation.

Repair Procedure

Use PVC adhesive found at your local marine store. We suggest Clifton Urethane adhesive. You can find the glue at www.NRSWEB.com/item #1901.

Before you begin, make sure you are working in a well-ventilated area, climate controlled to at least 70 degrees. It is advised that you wear protective gloves when working with chemicals.

After you have done the repair to the tube, it must sit undisturbed for at least 24 hours. When making a repair, do not inflate tube to maximum capacity. It is recommended that the tube be soft for all repairs.

Repairing Holes in the Tube

- 1. The repair of a small leak or puncture less than ½ inch can be done with a round patch, 3 inches diameter, and minimum.
- 2. Cut the round patch. Use the patches enclosed with your Inflatable Sport Boats.
- **3.** Place the patch over the area to be repaired, outline with a pen.
- 4. Wipe patch with clean towel. Using a clean towel, wipe area on the tube to be repaired.
- Apply 3 thin, even coats of adhesive to the surface of the boat and the patch. Wait 5 minutes between each coat. After the 3rd coat, wait 10-15 minutes before placing the patch on the boat skin.
- 6. Allow boat to sit for 24 hours. Don't rush the drying.
- 7. Air up the tube and check for leaks before use.

Large repairs of PVC, seams, bulkheads, and transom: Contact your boat dealer or manufacture if possible. Alternative is to send your tube to a professional inflatable boat repair company for repairs. You can look online for your nearest boat repair

company through Google's search engine; enter "inflatable boat repair." Most dealers of inflatable dinghy boats or white water rafts will have the ability to repair the tube.

TIP: If you try to repair a small break in the seam, use the repair instructions above. Be sure you allow for the contour of the tube when letting the area dry. It is sometimes necessary to glue and set a section, and after it is dry move onto the next section along the contoured area.

EC Declaration of Conformity

According to EC Directive "Recreational Craft" 94/25/EC, Boat XV.

We hereby declare that the boat described below; at the time it is placed on the market, meets in its design, type, and construction, the basic safety requirements of the: EC Directive for Recreational Craft.

In the event of alterations; modifications made to the boat which have not been approved by the manufacturer, Inflatable Sport Boats, and which affect the "basic safety requirements," this declaration no longer applies to that boat and is therefore null and void.

Designation of the boat: Inflatable Boat

Boat Type:	Dolphin Air Floor, Manta Ray, Shark, Killer Whale
Main Dimensions:	(8.8' × 5'), (8.8' × 5'), (9.8' × 5'), (10.8' × 5')
Design category:	C (designed for voyages in coastal waters, large bays, estuaries, lakes, and rivers where conditions up to, and including, wind forces 6 and significant wave heights up to, and including 2M may be experienced.)
Certification Module:	Aa
Application Directive:	EC-Dir. (94/25/EC) Recreational Craft

Warranty Registration

Within 30 days of purchase date, you must log onto www.inflatablesportboats.com and complete the warranty registration form. If this is not completed within the 30 days of the purchase date, the warranty will be voided.

Limited Warranty — *Inflatable Sport Boats*

Inflatable Sport Boats warrants it's Inflatable Sport Boats against defects due to substandard materials and workmanship, under conditions of normal use and service, as follows:

- 1. The fabric used in the construction of the hull, keel (where installed) and bottom of each Boat is warranted from manufacturing defects for a period of three (3) years.
- 2. The seams of each Inflatable Sport Boat are warranted for a period of three (3) years against separation or the subsequent loss of air.
- **3.** The transom on each Boat (where installed) is warranted against separation from the hull for a period of three (3) years.
- 4. Accessories supplied by Inflatable Sport Boats (floorboards, oars, motor bracket, handles, towing rings, pumps, valves) and all other attachments or accessories attached by Inflatable Sport Boats or purchased from Inflatable Sport Boats for the attachment to or use on Inflatable Boats are warranted for a period of one (1) year.

The above warranty may not be transferred or assigned to subsequent owners.

Warranty Exclusions

- 1. This warranty shall not apply to COMMERCIAL USE or Boats subjected to negligence, accident, improper operations or trailering, improper maintenance or storage, or other than normal use or application, as described in the Inflatable Sport Boats Owner's Manual, or to damage by circumstances beyond the control of Inflatable Sport Boats.
- 2. This warranty does not cover any damage to the Inflatable Boat because of puncture, tearing, ripping, abrasion, ordinary wear and tear, abuse, negligence or modification to the hull.
- Inflatable Sport Boats makes no other express warranties and intends no implied warranties. (If any implied warranties are found to exist, such implied warranties will be limited to a period of three (3) years. Inflatable Sport Boats will not be liable to injury or consequential damages of any kind resulting from a breach of warranty expressed or implied.)

Some states do not allow the limitations or exclusions of items above, so the above limitations or exclusions may not apply. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

The obligation of Inflatable Sport Boats under these warranties is limited to replacing or compensating, within a reasonable time, such Boat or part which fall within the warranty period and to the satisfaction of Inflatable Sport Boats be determined to have been defective in material or workmanship. The decision to replace or compensate for a particular Boat or part shall be at the election of Inflatable Sport Boats. Inflatable Sport Boats may require such Boat or part to be returned to an authorized dealer or other specific location for examination.

All returns must be authorized by Inflatable Sport Boats, to be covered warranty items. If, upon examination, defects are not found to be the responsibility of Inflatable Sport Boats, customer will be notified and requested to make decision of such Boat or part. Such Boat or part will be returned freight collect.

To initiate a warranty claim, it is the responsibility of the purchaser to contact the authorized Inflatable Sport Boats dealer or Inflatable Sport Boats, 2105 Pasqual Dr. Roseville, CA 95661 within a reasonable time after the discovery of the defect, providing date and proof of purchase, and details as to the nature of the defect. Taking photographs and emailing them may suffice if approved by Inflatable Sport Boats.

Manufacturer's Certificate of Origin

MANUFACTURER'S CERTIFICATE OF ORIGIN
1. Vessel Data:
Hull Identification Number: AST
Model Name:
Length: Beam: Draft:
Place of Construction: China
Hull Material:
Wood Steel Aluminum Fiberglass Other
2. Certification:
Do Hereby Certify that the facts recited herein are true ar
that I have personal knowledge of these facts because I:
A. Personally performed the construction
X B. Supervised the construction at and on behalf of
Inflatable Sport Boats
(Name of Company)
signature: <u>in</u> Chine of Company)
Date:

You will need the Manufacturer's Certificate of Origin to title and register your vessel. Please fill out with boat data provided in owner's manual and on CE plate. The H.I.N and C.I.N are the same thing and begin with AST; make sure you fill out the remaining #s and letters. They might also require a bill of sale/proof of purchase.



On Point Products 2105 Pasqual Dr., Roseville, CA 95661 www.inflatablesportboats.com | (530) 268-4757